

• IN THE BOX



BASE INSTALLATION





BASE DISMANTLING



• POWER DISPLAY



Green light full battery




Red light low battery





Red light flashes 3 times no power









CLICK 30 sec mixing

DOUBLE CLICK 3 min mixing


CLICK DURING MIXING stop

• USE STEPS






Remove the base



Put the cup and lid upside down in the dishwasher

• CLEANING METHOD



TROUBLESHOOTING

- Unable to start mixing, one LED flashes for 3 times.
- No battery, please charge.
- Mixing power is weak or mixing stops suddenly, and all LEDs flash for 3 times.
- Low battery.
 Excessive protein powder.
 Improper base installation.
- The base and bottle cannot be assembled.
- Foreign matter in the notch.

IMPORTANT NOTES

Usage Safety

1.To avoid damage and injury, please never pour water above 160 degrees Fahrenheit into the bottle. Too high temperature will cause pressure accumulation during operation, and may break the sealing, to gush from the top.

2.Please never heat the bottle in high temperature environment such as microwave oven and sterilization cabinet.Please never freaze this product.

3.Do not add dry ice, carbonated beverage and other liquids there are prone to generate high pressure. Do not add strong acid or alkali so as to prevent inner wall of container from corrosion.

4.Do not store dairy product or baby food in bottle for a long time.

5.Do not entirely soak the base in liquid for a long time to avoid failures.

Battery and Charging

1.Battery life mainly depends on your usage frequency. The statement of charge once for 1 month is calculated based on using 3 times a week under 30 sec mixing mode.Battery performance will gradually decline with the time of use.

2.When charging, LED indicator light will flash at current battery level, and all indicator lights are off after full charging.

3.At the end if mixing, if LED indicator lights turn off one after another, and the last LED light flashes quickly for 3 times , it means the battery should be charged.

